

TMA (D) Hammerfest:

BODØ CONTROL 126.70

ENHK


Elev **23'**/7m

N70 29.2
E022 08.4

*ILS/DME freq paired. LLZ offset 2°. No ILS GP AVBL.
LLZ not to be used 10° on either side of LLZ course.

RWY	ILS	RWY	ILS
		29*	111.50 VK 288°

HASVIK INFORMATION 119.90



CHANGES: COM - Airspace - Direction Arrows - OBST

© JEPPESEN, 2007, 2014. ALL RIGHTS RESERVED.

ENHV


Elev **44'**/13m

N71 00.6
E025 59.0

2.7 NM N Honningsvåg

*ILS/DME freq paired. No GP AVBL. LLZ not to be used outside 10° on either side of LLZ front course.

RWY	ILS	RWY	ILS
—	108.10* HV 207°		

VALAN INFORMATION **119.80**

CHANGES: ILS - VAR - Airspace - Direction Arrows - OBST.

© JEPPESEN, 2005, 2009. ALL RIGHTS RESERVED


HONNINGSVÅG

VALAN

NORWAY

19-2 02 OCT 09

JEPPesen



ALS - PLASI 08/26 (4.5°) - THRL - RL - RCLL - TWYL - APRON - WDI - OBSTL. ①

RWY No	Dimension (m) - Surface	TORA (m)	LDA (m)	Strength	Lights
08 26	880 x 30 Asphalt	840	800	PCN 15/F/B/X/U	☯

① PLASI 08: centered 4° N of RCL. Restricted to MAX 0.5 NM from THR 08.
 PLASI 26: centered 5° N of RCL. Restricted to MAX 1.0 NM from THR 26.
 Balked LDG guidance LGT: RWY 08 - 289m from THR 08, RWY 26 - 287m from THR 26.

CAUTION

Turbulence/ wind shear/ down draft may occur on APCH to/DEP from RWY 08 and RWY 26 when wind with more than 20KT from S. This may influence ACFT controllability and climb performance.

- LDG RWY 08: wind from S, above 20KT, may create windshear/turbulence in final RWY 08,
- LDG RWY 26: wind from S, above 25KT, may create variable wind on final RWY 26, and downdrafts on short final,
- DEP RWY 08: wind from S, above 27KT, may create variable wind and downdraft in TKOF sector RWY 08,
- DEP RWY 26: wind from S, above 27KT, may create variable wind and downdraft in TKOF sector RWY 26.

During summer season large bird concentrations W and E of AD may cause bird collision hazards.
 During summer season reindeer may occur close to and on AD.

PCL available. Activate ALS and lights at the AD by keying mike on AFIS freq continuously for at least 5 seconds. Lights remain on for 26 minutes.

LDG with HEL is only permitted on RWY east of TWY A.

COM Failure

- Squawk 7600,
- enter Holding 3.5 NM N of AD maintaining 500' (RH circuit),
- flash LDG LGT,
- watch TWR for visual signals.


HASVIK

HASVIK

NORWAY

19-2 09 MAY 14

JEPPesen



ALS - PLASI (4.5°) - THRL - RL - RCLL - TWYL - WDI - OBSTL.

RWY No	Dimension (m) - Surface	TORA (m)	LDA (m)	Strength	Lights
11 29	1039 x 30 Asphalt	859 909	819 799	PCN 15/F/B/X/U	☯

CAUTION:

Large bird concentrations (seagulls) may occur on and near the AD during summer season, especially close to extended RCL.

Reindeer may occur close to and on the movement area.

Ferry landing ESE of AD. Ferries may cross extended CL APRX 300m from THR.

PCL AVBL, activate ALS and RL by keying mike on AFIS freq continuously for at least 5 seconds, lights remain on for 26 MIN.

COM Failure:

- squawk 7600;
- hold 1 NM N of TWR at 1500';
- flash LDG LGT;
- watch TWR for visual signals.