

# AERODROME CHART - ICAO KARLOVY VARY

| RWY      | DIRECTION | THR                            | BEARING<br>STRENGTH              |
|----------|-----------|--------------------------------|----------------------------------|
| 11       | 110°      | 50°12'22,72"N<br>12°54'11,50"E | PCN 54/F/A/X/T                   |
| 29       | 290°      | 50°11'57,32"N<br>12°55'44,30"E |                                  |
| 12       | 110°      | -                              | 5600 kg (0,70 MPa)               |
| 30       | 290°      | -                              |                                  |
| TAXIWAYS |           | TWY A,C<br>TWY B               | PCN 27/F/B/X/T<br>PCN 43/F/C/X/T |
|          |           | TWY D,E                        | PCN 32/R/B/X/T                   |
|          |           | TWY F,V,W                      | 5600 kg/0,70 MPa                 |

